

**TEN PRODUKT WUNDERLICH MOŻESZ KUPIĆ W SKLEPIE BOXER-PARTS.**



**BOXER-PARTS JEST AUTORYZOWANYM DYSTRYBUTOREM WUNDERLICH.**

**PRZEJDŹ DO SKLEPU : [www.boxer-parts.eu](http://www.boxer-parts.eu)**

Instrukcja Wunderlich na kolejnej stronie

---

**THIS PRODUCT YOU CAN BUY IN BOXER-PARTS ONLINE SHOP.**



**BOXER-PARTS IS AUTHORIZED DEALER OF WUNDERLICH.**

**VISIT OUR SHOP : [www.boxer-parts.com](http://www.boxer-parts.com)**

Wunderlich instruction on next page



Fußrastentieferlegung



Footrest lowering



Pedane Basse



Repose Pieds Bas



Reposapiés Bajo

Art.Nr.: 31430-402







Bremsleitungsführung entfernen, Bremsbehälter lösen und mit der Leitung verlegen (Bild 3). Bremsleitung fixieren, darf nicht am Kardan anliegen.

Remove the brake line guide, loosen the brake tank and install with the cable (Fig. 3). The brake cable must not be attached to the kardan.













