

Februar 2006

January 2006

Anleitung: Motorschutz Verlängerung
BMW R1200 GS Adventure

Instruction: Engine Guard Extension
for Center Stand R1200GS ADV



Lieferumfang:

1 x Motorschutz Verlängerung
2 x Schelle gummiert 20mm
1 x Schelle gummiert 25mm
3 x Schraube Senkkopf M6x16
3 x Mutter selbstsichernd M6
3 x U-Scheibe M6

**Achtung: Wichtige Hinweise zur
Montage**

Kontrollieren Sie die Schraubenver-
bindungen in regelmäßigen Abständen.

Setzen Sie die Motorschutzverlängerung
von vorne auf den Seitenständer.

Befestigen Sie die
Motorschutzverlängerung mit den
beiliegenden Schellen mit Schrauben
Senkkopf M6x16, U-Scheiben M6 und
Muttern selbstsichernd M6.

Achten Sie bei der Montage darauf, dass
die Schellen und Muttern auf der
Rückseite / Innenseite liegen, so dass
eine glatte Oberfläche entsteht.

Contains:

1 x Engine Guard Extension Center
Stand
2 x Rubberized pipe clamps 20mm
1 x Rubberized pipe clamps 25mm
3 x Screw countersunk M6x16
3 x Nut self-locking M6
3 x Washer M6

Attention: important tips, explanations

Check the tightness of the guard in
regular intervals.

Set the engine guard extension on the
center stand.

Attach on the guard on the center stand
lower horizontal bar with two clamps and
with one clamp on the left side vertical
bar.

Install the clamps so that nuts are on the
inside leaving the sliding surface flat on
the outside.