

01-048-0340-0

Januar 2008

Januar 2008

DE20080312



**Anleitung:**  
Carbonprotector Kupplungsdeckel  
BMW F650(Twin)/800GS

**Installation Instruction:**  
Carbon Fiber Clutch Cover Guard  
BWM F650(Twin)/800GS

**Lieferumfang:**

1 x Schutz Kupplungsdeckel Carbon  
1 x Tube Silikon  
(hochtemperaturbeständig)

**Contains:**

1 x Clutch cover guard carbon fiber  
1 x tube silicone (high temperature  
resistant!)

**Achtung! Wichtige Hinweise**

**Kupplungsdeckel vor der Montage  
sorgfältig entfetten! Kontrollieren Sie  
bitte von Zeit zu Zeit den Sitz des  
Carbonteils!**

**Attention! Important information!**

**Degrease clutch cover carefully  
before the assembly! Check adhesion  
of the guard in regular intervals.**



**Montage:**

1. Entfetten / reinigen Sie den Deckel für die Kupplung sorgfältig
2. Bestreichen Sie die Innenseiten des Carbonteils mit dem mitgelieferten Silikon wie in Bild 1gezeigt.
3. Drücken Sie das Carbonteil sorgfältig fest. Achten Sie darauf, dass alle Kanten sauber anliegen! Anschließend den Deckel unter Druck mindestens 12 Stunden fixieren, z. B. mittels Spanngurt (siehe Bild 2)

**Installation:**

1. Clean and degrease clutch cover carefully
2. Apply silicone at the innerside of the cover guard as shown in pic. 1
3. Press in the guard carefully against clutch cover. Make sure, that all edges fit! The cover guard has to be fixed under pressure or 12 hours (with a strap, for example, as shown in pic. 2)

