

01-048-0406-0



DE20100827

Januar 2008

Anleitung: Abdeckkappe Schwinge/ Steckachse rechts **BMW F650(Twin)/800GS**

Lieferumfang:

1 x Abdeckung rechts

Achtung! Wichtige Hinweise

Passt nur rechts!

Bei der Montage gleichmäßig, aber kraftvoll drücken! Auf keinen Fall mir einem "Schlag" montieren, weder mit einem Werkzeug, noch mit dem Handballen!

Gegebenenfalls die Abdeckkappe vorher auf einer Heizung erwärmen.

Montage

- 1. Untergrund reinigen
- 2. Abdeckung (an der endgültigen Position) 2. Clip on the cover (on final position). oben einhängen und nach unten einklippsen!

January 2008

Instruction: Cover for swingarm/ main shaft cover right **BMW F650(Twin)/800GS**

Contents:

1 x cover right

Attention: important tips, explanations

Fits only the right side!

While mounting, push steady but with force! Certainly not with a "kick", neither by using a tool, nor with the heel of hand! If necessary warm the cover on a radiator.

Assembly

- 1. Clean the subsurface
- First the upper side, then push the lower side in.

